



SCREEN PRINTING PLACEMENT GUIDE



FRONT LEFT

3" from neck seam to
image centerline



FRONT POCKET

0.25" from top of pocket
to bottom of image



FRONT FULL

2.5" from neck seam to
top of print image
- images 6" or taller



FRONT SHORT

5" from neck seam to
image centerline
- images 3.5" or shorter



BACK FULL

4.5" from neck seam to
top of print image
- images 6" or taller



BACK SHORT

7" from neck seam to
top of print image
- images 5" or taller



BACK YOKE

2" from neck seam to
top of print image



BACK HOODIES

7" min. from neck seam
to top of print image



SLEEVE SHORT

0.5" from sleeve seam
to bottom of print



SLEEVE LONG

Image start 2" from cuff
centered on sleeve crease

THIS IS MERELY A GUIDE... LIKE RAFIKI...

(From the Lion King)

This document is merely a guide to standard placements for these different print locations. There may be longer sleeves, or a shorter hood, so use your best judgment based off of these principles. Stick to these measurements as best as you can. And listen to Rafiki...